Moulded walls

Light, internal walls constructed as moulded partitions are either of the Monier or Rabitz type.

Both are made by erecting one-sided formwork, followed by either a mesh reinforcement (Monier) or wire netting (in a variety of designs), and thereafter by pouring layer by layer as the formwork on the opposite side is gradually raised. The connection to adjacent building elements is principally the same as for other walls.

Due to the laborious work process involved, the use of such partitions is not particularly widespread.

